Remote Control Access to Setup Menu Functions

To access the special setup menu functions below...
Press the Source button and then the Program button. Don't hesitate between these presses. Three dashes appear at the left of the display.
Then enter the three numbers to the left of the desired function below.
The Play button "Executes" a command. The Stop button "Exits" the menu.

6 1 1   **Normal Playback**
6 2 2   Repeat All song Playback
6 2 3   Repeat Toggle, with wrap around (1 song/all song/normal)
6 3 1   Random 1 Song Play
6 3 2   Random Songs 1 program
6 3 3   Random All Song Play
6 3 4   Random Toggle, with wrap around (single/program/all/normal)
7 1 1   **Upgrade Appl From Card**
7 1 2   **Upgrade Appl From CD-ROM**
7 2 1   **Upgrade Demo From Card**
7 2 2   **Upgrade Demo From CD-ROM**
7 3 1   Copy Record memory to Card
7 4 1   **Copy SAL files CD-ROM to Card (no overwrites)**
7 4 2   Hard Copy SAL files CD-ROM to Card (overwrite)
7 5 1   Upgrade System From Card
7 5 2   Upgrade System From CD-ROM
8 1 1   2 Outputs (Out-R1 / Out-Unmix-R2 / Mute-F1)
8 2 1   Midi Source is connected to a File Player
8 2 2   Midi Source is connected to a Record Strip
8 3 1   Main Output is Mono
8 3 2   Main Output is Stereo
8 4 1   Metronome Signal
9 1 1   Midi Delay 0 msec (pianomation)
9 1 2   Midi Delay 500 msec (synth)
9 2 1   Pianomation plays all pianos
9 2 2   Pianomation plays piano on channel 1
9 2 3   Pianomation plays all musical instruments
9 2 4   Pianomation plays all midi data
9 3 1   Standard (Out-R1 / In-R2 / HP-F1)
9 3 2   sing-Along (Out-R1 / Mute-R2 / Mic-F1)
9 3 3   silent-Piano (Mute-R1 / Mute-R2 / HP-F1)
9 3 4   Barcus Berry (Out-R1 / Mic-In-R2 / HP-F1)
9 3 5   2 Outputs (Out-R1 / Out-Unmix-R2 / Mute-F1)
9 5 1   **Show Serial Number**
9 5 2   **Show Software Version**
9 5 3   **Show Pianomation Controller Version**
9 6 1   **Start Test & Alignment Routine**
9 8 1   Restore All parameters to default
9 7 2   Format CompactFlash Card